


# Calibration Square


**UPDATE:** Your unit has been upgraded with our new calibration square. Please use this drawing for reference during calibration.



Place the calibration arm in this position during calibration of the unit. Position shown is for determining the center position.



Remove the calibration arm and move the cyclic bar through the opening for unit storage.



Place the calibration arm in this position for normal operation of the unit.